
HYGIENE PLAN AND USE Sallósphere®

It is very important to follow the instructions and recommendations for use. Place these instructions in the front of the dishwasher.



To achieve a satisfactory result and make the most of Sallosphere®, ensure the use of one Sallosphere® in every rack.

In high use establishments, it is enough to use one Sallosphere® every two racks to achieve a premium result.

- -Make sure that nothing covers totally or in part the Sallosphere®
- -Make sure your sprinklers are working properly: rotation, pressure, etc.
- -Make sure your Sallosphere® is correctly positioned: Face up and on one side of the rack, never in the center
- -Make sure your dishwasher reaches 50 °C to 70 °C in the washing process and 70 °C to 80 °C in the rinse

Warnings

- -Do not handle Sallosphere®
- -Do not shake it and do not put it faced down, the liquid that releases is corrosive.
- -Do not remove the dosing cover, nor the sponges, nor the fibers.



PEERLESS JAL PTY LTD Head Office: 10-12 Raglan Street PRESTON VIC 3072 Phone: 1800 800 248