

# How to dispense Microaid



## STEP 1

- ▶ Place nozzle on bag end  
Be careful of spillage  
when placing nozzle on  
pouch.

Grip the pouch around  
the hard plastic rim and  
push nozzle on.



## STEP 2

- ▶ Slip the nozzle into the  
circular rim



## STEP 3

- ▶ Place the hole in the  
pouch on the hook to  
secure in place



## STEP 4

- ▶ Squeeze the nozzle into  
the spray bottle that  
has already been filled  
with water.

Squeeze once for lightly  
soiled areas. Squeeze  
twice for heavily soiled  
areas.

\*The spray bottle in the image has a microaid label on the bottle. This can be obtained from the back of your microaid pouch. As part of occupational health and safety it is essential to ensure all spray bottles are clearly marked.

- Do not pull down on the nozzle
- Squeeze the middle of the nozzle
- Do not dislodge one way valves at each end of nozzle