

Duroplus L Additive

1 PRODUCT DESCRIPTION

Additive for additional enhancement of scratch resistance and for additional matting effect. For **Dr. Schutz PU Sealer/Waxnomor**, **Dr. Schutz PU Sealer 100/Waxnomor 100** and **Dr. Schutz PU Anticolor/Marknomor**. Addition to the base lacquer of up to 20% is possible. Easy to use. Effective in result.

2 AREAS OF APPLICATION

To combine with all Dr. Schutz waterbased sealers in their recommended areas of application. Ideal for all mat and high wear surfaces. Also for dark and scratch sensitive substrates..

3 APPLICATION

Shake up very well! **Dr. Schutz DuroPlus L** is firstly to be thoroughly and evenly mixed into the base lacquer. Then mix in for the base lacquer calculated amount of Crosslinker as normal. Application is the same method for the basic lacquer system.

Please note:

- Make a sample of desired matting before application.
- Note the mixed in amount of DuroPlus L for later references.
- Mix enough lacquer for one layer in the whole area. Additional mixing later on might lead to gloss deviations.
- Dosage recommended on a scale.

4 CONSUMPTION

Depending on mixing ratio. Typically Coverage: 200 m²/l (5 g/m²) at a lacquer consumption of 50 ml/m² and an addition of 1:10.

5 DRYING TIME

Same as given for the basic lacquer.

6 STORAGE

Protect against frost. Store in a cool, dry place. Will keep for 24 months in unopened, original canister from the date of manufacture. Keep coating materials out of the reach of children.

When stored in varying temperatures and/or in an opened canister, dried parts can form. If so, sieve these out before using.

Duroplus L Additive

7 TECHNICAL DATA

Contained substances: water, polyacrylate,, silicic acids, minerals,, waxes, additives. Contains 1,2-benzisothiazol-3(2H)-one. May produce an allergic reaction.

voc (g/l) 2 (ISO11890).

ADR/RID: not a dangerous good as defined by transport regulations.

CLP/GHS: labelling not necessary.

Emptied canisters can be disposed of in household waste, or taken to a recycling centre.

8 SPECIAL NOTES

9 CROSS-REFERENCE

Our following publications in their updated form are valid as an integral part of this fact sheet:

- General notes on the application of Dr. Schutz finishes
- Safety data sheet.

The quoted printed matter, as well as this product information in its updated form, is available on our homepage www.peerlessjal.com.au or on request from the address quoted below.

Dr. Schutz – We Care About Floors

Peerless JAL
Head Office
6-12 Raglan St, Preston
VIC, 3072

Ph: 1800 800 248
Fax: 03 9416 8516
Email: sales@peerlessjal.com.au
www.peerlessjal.com.au

The above advice for technical application is given to the best of our knowledge and according to the latest state of technology. Therefore, if our products are used carefully heeding the advice given on their application, as well as following our suggested procedures with the materials intended for use with these products, no damage shall occur. However, our products are used outside and beyond our possible control, and are therefore subject to your own responsibility, which does not release you from the obligation to check for yourself whether our supplied products are suitable for your intended purpose and procedure. Therefore our notes and advice are not legally binding and cannot be used against us as grounds for liability - which includes the rights and protection of any third party. The relevant recommendations, guidelines and standard norms are to be observed, as well as the recognized technical rules. On publication, this product information replaces and supersedes the validity of any previous versions.